

Wi-Fi Smart Plug Quick Setup Guide

HUMAX

Specifications

- **Model:** UK 3 Pin Smart Wi-Fi Plug
- **Wireless Type:** Wi-Fi 2.4GHz
- **Voltage:** AC100-240V
- **Rated Current:** 16A (Max)
- **Working Temp:** -20~50°C
- **Wi-Fi Frequency:** 2.4GHz
- **AC Frequency:** 50-60Hz
- **Dimensions:** 58 x 55 x 55 mm
- **Material:** PC
- **Supported Systems:** Android & iOS

App Download & Registration



Scan the QR code to download the **Humax Smart Living** app.

Alternatively, search for **Humax Smart Living** in either the **Apple App Store** or **Google Play Store** to download and install the app.

Open the **Humax Smart Living** app, follow the on-screen prompts and then tap "**Register**" to create an account using your phone number or email address.

Once registered, proceed to adding your device.

Add Device (Quick Mode)

Before you begin:

• **Make sure your phone/tablet is powered on and connected to your Wi-Fi network.**

1. Plug your smart device in to a wall outlet and switch on the power. Press and hold power button for at least 5 seconds until the indicator light begins to flash.
2. On your phone/tablet, open the **Humax Smart Living** app and tap “+” icon in the top right. Select the device type, and confirm the indicator light is still flashing. The device should automatically fetch your Wi-Fi network details.
3. Tap confirm to connect to the device. When the prompt “**Successfully added 1 device**” appears, the connection is complete and your device should appear in the device list on the app.

Add Device in AP Mode (Advanced)

If the device doesn't connect using Easy Mode, users can add devices using AP Mode.

1. On your phone/tablet, open the **Humax Smart Living** app and tap the “+” icon in the top right. Select “**Add Device**”.
2. Under “**Add Manually - Socket**”, select “**Plug(BLE+WiFi)**”.
3. In the top right, please change mode from default (**EZ mode**) to **AP mode**
4. Proceed with the on-screen instructions on your phone/tablet.

Contact & Support

We hope you enjoy using your device. If you require any assistance, feel free to contact us.

Phone: **0344 318 8800**

Email: **uksupport@humax-digital.co.uk**

Our UK based support team is available between **Mon-Fri 9am-5pm.**

For more information visit:
uk.humaxdigital.com/support